



Assembly instructions for deckchair Quentin

1.



2.



3.



4.



5.



6.



7.



8.



9.





Safety and warning instructions

- Only use the deck chair as a seat, not as a ladder or climbing aid.
- Do not exceed the maximum load of 120 kg (50 kg for Greta).
- Avoid rocking, swinging, or placing heavy loads on the side of the deck chair to prevent it from tipping over.
- Ensure that the deck chair is standing on a level and stable surface.
- Use suitable glides for the floor covering to prevent damage.
- When opening and closing the deck chair, make sure that no fingers or other body parts get caught.
- Before use, ensure that the deck chair is properly locked in the desired position to prevent unwanted tipping.
- Do not use a deck chair with visible damage.
- Do not leave children unattended on the deck chair.
- Make sure that you have unfolded the deck chair correctly and completely, as described in the instructions.
- Please note that the deck chair is not weatherproof.